

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125

Phone: (216) 447-1777 or (800) 548-4867

Fax: (216) 447-3416

www.dawn-ent.com

## UNIVERSAL INSTALLATION INSTRUCTIONS

PART NUMBER: LS/ X2

FOR: All makes and models

EFFECTIVE: 06.02.08

### SELF ADHERING INSTALLATION – NO DRILLING REQUIRED

#### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. For proper installation of the Lip Sportwing®, clean the surface where the Sportwing® is to be installed using the alcohol pads enclosed. Wipe off any excess residue with a clean cloth.
2. Leave the liner on bottom area of the Sportwing® place on the rear-most edge of the deck lid above the defined trunk crease. The rear of the Sportwing® should follow the rear most defined trunk crease. Center the from left to right Sportwing® on the deck lid, when satisfied make a mark on either end for reference. **Note: DO NOT STRETCH PART DURING INSTALLATION!!!! In extremely hot weather the part will stretch, it is important during installation that finished ends of Sportwing® should end equal at each end of the deck lid.**
3. The Recommended temperature of the vehicle and Sportwing® for proper installation should be at least 75°F/24°C for proper adhesion. Make sure Sportwing® is warm and flexible. **Note: We recommend using a heat gun or hair dryer to warm the surface of the vehicle and the Sportwing®).**
4. Remove the liner from the bottom of the Sportwing®, keeping fingers off adhesive mounting-tape, **lightly tack** the Sportwing® onto deck lid from your reference marks made earlier, as shown in Diagram A. Continue following curvature of the deck lid. If not satisfied with the flow, then carefully lift the Sportwing® and start over. When satisfied, press into place with a soft cloth.
5. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc

Diagram A.



