

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

SS

PART NUMBER: ACC06-2DR  
FOR: 2006 + Honda Accord 2 Door  
EFFECTIVE: 01.16.06

### INSTALLATION PACKAGE INCLUDES:

- A) 4 – M6 – 12 – (1/2") Screws
- B) 4 – Lock Washers
- C) 4 – Hole Locators
- D) Adhesive Pads (for an unpainted Sportwing®)
- E) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Open the trunk and place a protective cover inside the trunk to capture any metal shavings, close trunk. Starting on the drivers side, measure 9-3/8" from the tip of the deck lid where it meets the rear window, **see Diagram below**. Place a mark with a grease pencil. Repeat procedure on passenger side.
2. Place the Sportwing® on the marks made in Step #1. As you face the rear of the car, the front tips of the Sportwing® will rest on these marks, **see Diagram below**. Center the Sportwing® exactly from left to right. Using a grease pencil, outline both mounting feet.
3. Place hole locator strips provided into four (4) mounting holes of the Sportwing®, two (2) each side (**NOTE: a small piece of masking tape is helpful in holding hole locators in place**).
4. Place the Sportwing® on closed deck lid and align back onto outline marks.
5. Using masking tape, secure hole locators to deck lid of vehicle. Remove Sportwing® by lifting straight up, leaving hole locators secured to deck lid.
6. Using a 1/8" drill bit or similar, drill through the center of each hole locator, through the top panel of the deck lid only. **IMPORTANT! We insist you use a drill stopper to prevent from drilling into the rain channel of the trunk! You will only need to extend the drill bit no more than 1/2" past drill stopper. Electrical tape, wrapped tightly around drill bit will work as a drill stopper.** Next, using a #1 uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open up the 1/8" pilot holes that you made earlier in this step to 3/8". After opening holes to 3/8", apply chromate primer or touch up paint to edges of the holes.
7. Holding onto the Sportwing®, place the Sportwing® back onto the outline marks made in Step #2 and using screws and lock washers provided, finger tighten all four threaded sleeves of mounting feet. Next, tighten all four screws firmly. **DO NOT OVER TIGHTEN.**
8. Clean up any metal shavings that might have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

