

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

SS/ST

PART NUMBER: ACC06-4DR
FOR: 2006 + Honda Accord 4 Door
EFFECTIVE: 07.18.07

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 3/4" Self Tapping Screws
- B) 4 – 5/16" Lock Washers
- C) 4 – Paper Hole Locators
- D) Adhesive Pads (*for an unpainted Sportwing®*)
- E) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Open the trunk and place a protective cover inside the trunk to capture any metal shavings, close trunk. Starting on the drivers side, measure 8 3/4" from the tip of the deck lid where it meets the rear window, **see Diagram below**. Place a mark with a grease pencil. Repeat procedure on passenger side.
2. Leaving the paper liner on bottom of mounting feet, place the Sportwing® on the marks made in Step #1. As you face the rear of the car, the front tips of the Sportwing® will rest on these marks, **see Diagram below**. Center the Sportwing® exactly from left to right. Using a grease pencil, outline both mounting feet.
3. Align HOLE LOCATOR STRIPS, provided, over four (4) mounting holes of Sportwing® mounting feet, two (2) each side. Align hole in center of HOLE LOCATOR exactly over hole in bottom of mounting foot (**NOTE: a small piece of masking tape is helpful in holding hole locators in place**).
4. Place the Sportwing® on closed deck lid and align back onto outline marks.
5. Using masking tape, secure HOLE LOCATOR STRIPS to deck lid of vehicle. Carefully, remove the Sportwing® by lifting straight up, leaving HOLE LOCATORS secured to deck lid.
6. Using a 1/8" or similar drill bit, drill through the center of each HOLE LOCATOR, through the top panel of the deck lid only. **IMPORTANT!** We insist that you use a drill stopper to prevent from drilling into the rain channel of the trunk. You will only need to extend the drill bit no more than 1/2" past drill stopper. Electrical tape, wrapped tightly around drill bit will work as a drill stopper. Next, using a #1 uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open up the 1/8" pilot holes that you made earlier in this step to 3/8". After opening holes to 3/8" apply chromate primer or touch up paint to the edges of the holes.
7. Peel the paper liner off the bottom of the mounting feet. Lightly tack the Sportwing® onto the outline marks made in Step #2 while holding the Sportwing® in place. Open the deck lid, check to see that the 3/8" holes in deck lid align with the pre-drilled holes in the bottom of the mounting feet. When satisfied with alignment, close the deck lid and press firmly into place. Open the deck lid and using ratchet with 5/16" socket, install 3/4" BLACK SCREWS with LOCK WASHERS. Tighten firmly. Repeat procedure on passenger side.
8. Clean up any metal shavings that might have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

