

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: AURA  
FOR: 2007 + Saturn Aura  
EFFECTIVE: 08.03.06

### INSTALLATION PACKAGE INCLUDES:

- A) 4 – ¾" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Flat Washers
- D) 2 – Black Hole Caps
- E) Adhesive Pads (for an unpainted Sportwing®)
- F) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Remove trunk cover. Starting on the drivers' side, measure 11 ¼" from tip of the deck lid where it meets the rear window. Mark with a grease pencil. Repeat procedure on other side. **See Diagram A below.**
2. Leaving the paper liner on bottom of mounting area, place the Sportwing® on the marks made in Step #1 so that as you face the rear of the car, the front edge of the Sportwing® rests on these marks. Next, center the Sportwing® from left to right. Outline Sportwing® with a grease pencil (**NOTE: because of curvature of Sportwing® when holding down drivers' side, passenger side will be slightly up from vehicle. After fastening drivers' side, passenger side will pull down flush**). Set Sportwing® aside.
3. Set the Sportwing® aside and position the template provided on the drivers side outline made in Step #2 (**NOTE: before drilling through drivers side of deck lid and secondary panel make sure that the factory wire harness in drilling area is pushed aside**). Using a ¼" drill bit, drill down through the spots indicated on the template for your mounting holes through the top panel and through the secondary panel also. Repeat on passenger side by flipping template over.
4. Open the trunk. Using a 5/8" hole saw, open the ¼" pilot holes in the secondary panel to 5/8". This will give you access for your socket wrench later in the installation. Repeat procedure on other side. Hole caps have been provided upon finishing.
5. Close the trunk and remove the paper liner from the bottom of the mounting feet and place the Sportwing® back onto the outline marks made in Step #2. Press firmly into place.
6. Open the trunk, IMPORTANT: switching to your 5/32" drill bit, drill up into the bottom of the mounting feet using the pilot holes drilled in Step #3 (**NOTE: when drilling, you must use a drill stopper to prevent from drilling through the top of the Sportwing®**). Using a ratchet with 5/16" socket, install mounting screws with lock washers and tighten firmly. **DO NOT OVER TIGHTEN.** Repeat procedure on other side. Use hole plugs provided to cover holes in secondary panel.
7. Clean up any metal shavings that might have fallen into the trunk and you are done. The installation should take no longer than 30 minutes. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

