

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: AVEO09-5DR  
FOR: 2009 + Chevrolet Aveo 5 Door Hatchback  
EFFECTIVE: 03.25.10

### INSTALLATION PACKAGE INCLUDES:

- A) 2 – M-6 x  $\frac{3}{4}$ " Mounting Screws
- B) 2 – Lock Washers
- C) 2 – Flat Washers
- D) 2 – Paper Hole Locators
- E) Adhesive Pads (for unpainted Sportwing®)
- F) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Wear proper eye protection and make sure the area where Sportwing® will be installed is clean.
2. Leaving the plastic liner on bottom of mounting area if Sportwing®, center the Sportwing® left to right on the hatch of the vehicle and position the Sportwing® for installation, making sure the Sportwing® is flush to the hatch. Using a grease pencil, outline the outer mounting area of the Sportwing®. Set the Sportwing® aside.
3. Next, place the Sportwing® upside-down on a soft cloth so you do not scratch the painted top surface. Using two (2) paper hole locators, provided, remove the liner from the hole locator to expose the adhesive, place the cut out hole in the hole locator centered exactly over the two (2) mounting holes of the fastening area of the Sportwing®. **See Diagram below.** Making sure that the hole locators do not move (**NOTE: a small piece of masking tape is helpful in holding hole locators in place**) carefully place the Sportwing® back onto the outline marks on the deck lid that you made in Step #2 (**NOTE: leave plastic liner on bottom of mounting area**).
4. When Sportwing® is centered on the outline marks made in Step #2 and making sure that the two (2) hole locators did not move, tape the two (2) hole locators to the hatch using masking tape. Next, carefully lift the Sportwing® off of the hatch, leaving the hole locators taped to the hatch.
5. Using a 1/8" or similar drill bit, drill a 1/8" pilot hole in the exact center of the two (2) hole locators, through the top panel of the hatch only.
6. Remove the hole locators from the hatch and using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) open the two (2) 1/8" pilot holes to 3/8".
7. Apply Zinc Chromate Primer or touch-up paint on the edges of the two (2) 3/8" holes that you drilled in the hatch.
8. Remove the plastic liner from the tape on the bottom of mounting area of the Sportwing® and lightly tack the Sportwing® back onto the outline marks that you made in Step #2. The two (2) mounting holes on bottom of Sportwing® should align with the two (2) 3/8" mounting holes that you made in top panel of the hatch. If 3/8" holes do not align with mounting holes of Sportwing®, lift Sportwing® off of the car and re-align. If holes do not align, you may need to left Sportwing® off of car and open to 3/8" holes to the next size, 7/16".
9. Using mounting screws with lock washers and flat washers, provided, install mounting screws into mounting holes and partially tighten the two (2) mounting screws. After screws have been started, tighten evenly until all screws are tight. **DO NOT OVER TIGHTEN.**
10. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

