

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: **BCM-16**
FOR: Bumper Cover Moldings for:
2007 & up Dodge Caliber
2003 – 2008 Infiniti FX35/45 • 2009 & up Infiniti FX35/FX50
2009 & up Nissan Murano • 2009 & up Nissan Rogue
EFFECTIVE: 03.30.09

INSTALLATION PACKAGE INCLUDES:

- A) Alcohol Wipes
- B) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **LOCATION:**
See Diagram below.
2. **CLEAN & PREP:**
For proper installation of bumper cover molding, clean the surface where the bumper cover molding is to be installed using alcohol wipes enclosed. Wipe off excess residue with a clean cloth. Where cooler temperatures prevail, make sure that the bumper cover molding is at room temperature. The recommended surface of vehicle temperature should be at least 75°F/24°C for proper installation. If the surface is cold, use a heat gun or hair dryer to warm before proceeding with the installation.
3. **INSTALLATION:**
Leaving the red liner on the bottom of the mounting tape of bumper cover molding, place the bumper cover molding onto the bumper **as shown in Diagram A below**. Center left to right. When satisfied, with alignment, outline each outer edge and rear area, **as shown in Diagram B below**.

Remove red liner from mounting tape and lightly tack back onto the outline marks that you made in the beginning of Step #3 (**NOTE: if not satisfied with alignment, re-install**). **DO NOT TOUCH THE EXPOSED ADHESIVE** with your fingers as the installation is being done. After bumper cover molding has been installed and you are satisfied with the alignment, press firmly into place with a soft cloth.

DIAGRAM A



DIAGRAM B

