

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: **BCM-52**  
FOR: Bumper Cover Molding for:  
2007 & up Ford Edge  
2007 & up Lincoln MKX  
2008 & up Scion xB • 2008 & up Scion xD  
2010 & up Subaru Outback  
EFFECTIVE: 03.20.09

### INSTALLATION PACKAGE INCLUDES:

- A) Alcohol Wipes
- B) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **LOCATION:**

See Diagram below.

2. **CLEAN & PREP:**

For proper installation of bumper cover molding, clean the surface where the bumper cover molding is to be installed using alcohol wipes enclosed. Wipe off excess residue with a clean cloth. Where cooler temperatures prevail, make sure that the bumper cover molding is at room temperature. The recommended surface of vehicle temperature should be at least 75°F/24°C for proper installation. If the surface is cold, use a heat gun or hair dryer to warm before proceeding with the installation.

3. **INSTALLATION:**

Leaving the red liner on the bottom of the mounting tape of bumper cover molding, place the bumper cover molding onto the bumper **as shown in Diagram A below**. Center left to right. When satisfied, with alignment, outline each outer edge and rear area, **as shown in Diagram B below**.

Remove red liner from mounting tape and lightly tack back onto the outline marks that you made in the beginning of Step #3 (**NOTE: if not satisfied with alignment, re-install**). **DO NOT TOUCH THE EXPOSED ADHESIVE** with your fingers as the installation is being done. After bumper cover molding has been installed and you are satisfied with the alignment, press firmly into place with a soft cloth.

DIAGRAM A



DIAGRAM B

