

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: CAMARO
FOR: 2010 + Chevrolet Camaro
EFFECTIVE: 06.23.10

INSTALLATION PACKAGE INCLUDES:

- A) Alcohol Wipes
- B) 4 – Paper Hole Locators
- C) 4 – Tape Gaskets
- D) 4 – M-6 x 5/8" Mounting Screws
- E) 4 – Lock Washers
- F) 4 – Flat Washers
- G) Instruction Sheet

EXTRA TOOLS NEEDED:

- 1. 1/8" or similar Drill Bit
- 2. Uni-bit

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

** Open deck lid. See **Diagram A on back of sheet.** Remove the four (4) black factory plugs from the secondary panel of the deck lid. Removing plugs will give you access to the top panel of the deck lid when installing mounting screws later in the installation. **

1. Close the trunk. Use Alcohol Wipes, provided, to clean the area where Sportwing® will be installed. See **Diagram on back of sheet.** Along the drivers side, measure down **14 ¾"** from the tip of the trunk lid where it meets the rear window glass, back towards the rear of the car and make a mark with a grease pencil. Repeat on passenger side.
2. Place the Sportwing® on the marks made in Step #1. See **Diagram B on back of sheet.** As you face the rear of the car, the front tips of the Sportwing® will rest on these marks. Center the Sportwing® exactly from left to right. Using a yellow grease pencil, completely outline the Sportwing®. Remove the Sportwing® from the trunk.
3. Next, place the Sportwing® upside-down on a soft cloth so you do not scratch the painted top surface. Using four (4) paper hole locators, provided, remove the liner from the hole locator to expose the adhesive. Place the cut out hole in the hole locator centered exactly over the four (4) threaded sleeves of the fastening area of the Sportwing®. Make sure that the hole locators do not move (**NOTE: a small piece of masking tape is helpful in holding hole locators in place**) carefully place the Sportwing® back onto the outline marks on the deck lid, that you made in Step #2.
4. When Sportwing® is centered on outline marks made in Step #2, and making sure that the four (4) paper hole locators did not move, tape all four (4) hole locators to the deck lid using masking tape. Next, carefully lift the Sportwing off the deck lid, leaving the hole locators taped to the deck lid.
5. Using a 1/8" or similar drill bit, drill a 1/8" pilot hole in the exact center of all four (4) hole locators. Remove the hole locators and using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) open the four (4) 1/8" pilot holes to 3/8".
6. Apply Zinc Chromate Primer or Touch-Up Paint on the edges of the four (4) 3/8" holes that you drilled in the deck lid.
7. **IMPORTANT:** Place the four (4) round tape gaskets, provided, centered over the four (4) 3/8" holes that you made in the deck lid in Step #5.
8. Remove the plastic liner from the double-sided tape on the bottom of the mounting area of the Sportwing® and lightly place the Sportwing® back onto the outline marks that you made in Step #2. Open the deck lid and check to see that the four (4) 3/8" holes that you made in the deck lid align with the four (4) threaded sleeves of the mounting area of the Sportwing®. If satisfied with the alignment, press the Sportwing® firmly in place. If the holes do not align, you will need to reposition the Sportwing® until satisfied with the alignment. Using fastening screws with lock washers and flat washers, provided, install screws into threaded sleeve. Tighten all four (4) screws. **DO NOT OVER TIGHTEN.** Replace black factory plugs into secondary panel.

9. Clean up any metal shavings and you are done. If you have any questions or if you would like information about other quality Sportwing® products please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A



DIAGRAM B

