

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: CAR01
FOR: 2001 + Chrysler Town & Country
Dodge Caravan
EFFECTIVE: 04.02.01

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 5/8" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Black Hole Caps
- D) 2 - Templates
- E) Adhesive Pads (for unpainted Sportwing®)
- F) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Wear proper eye protection and make sure area where Sportwing® will be installed is clean.
2. Leaving paper liner on tape, center Sportwing® left to right on vehicle and position the Sportwing® for installation. Using a grease pencil, outline both mounting feet. Set Sportwing® aside.
3. **See Diagram A below.** Using templates provided, place template on designated area and using a 5/32" drill bit with drill stopper, drill down through the two spots indicated on template, making sure that you don't drill into rain channel (**NOTE: do not extend drill bit 1/2" past drill stopper**). Flip template over for passenger side and repeat procedure.
4. Open hatch and using smaller template provided, **see Diagram B below**, tape template to designated area of secondary panel. Drill a 5/32" pilot hole through secondary panel only. Next, using a 5/8" hole saw, open this pilot hole to 5/8". Hole caps have been provided to cover these holes upon finishing. This hole will give you access to drill up into the Sportwing® and fasten screw later in Step #6.
5. Peel liner from tape and place Sportwing® back onto the outline marks made in Step #2. Press firmly into place.
6. Open the hatch (**NOTE: prior to drilling, it is important to protect the installation area. Place a drop cloth in this area to prevent shavings from accumulating in drip well channel and bumper area**). Using a 5/32" drill bit, drill through the pilot holes up into the mounting feet. Install mounting screws with lock washers and tighten. **DO NOT OVER TIGHTEN.**
7. Clean up any metal shavings that may have fallen into the trunk. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A



DIAGRAM B

