

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 642-5505
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: CH-RT11
FOR: 2011 + Dodge Charger
EFFECTIVE: 29 APR 2011

INSTALLATION PACKAGE INCLUDES:

- A) 4 . M6 x 5/8+Mounting Screws
- B) 4 . Lock Washers
- C) 4 . Flat Washers
- D) 1 . DriversqSide Template . Flip template over for passenger side
- E) Adhesive Pads (*for unpainted Sportwing®*)
- F) Instruction Sheet

EXTRA TOOLS NEEDED:

- 1. 1/8+Drill Bit
- 2. Uni-Bit

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **Remove trunk liner.** Leaving the paper liner on the bottom of the mounting feet, measure 17 ¾" from the tip of the trunk lid back toward the front . most area of the mounting feet, along the driver's side. **See Diagram below.** Repeat procedure on passenger side. Next, center the Sportwing® left to right on deck lid. Outline both mounting feet using a grease pencil.
2. Set the Sportwing® aside and position the driversqside template, provided, on the driversqside outline made in Step #1. Flip template over for passenger side. Using a 1/8+or similar drill bit, drill down through the exact center of the spots indicated on the template for your mounting holes through the top panel of the deck lid. Next, using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open the 1/8+ pilot holes that you made in the top panel of the deck lid to 3/8+.
3. Apply Zinc Chromate or touch-up paint on the edges of the four (4) 3/8+holes that you drilled in the deck lid.
4. Remove the paper liner from the bottom of the mounting feet and place the Sportwing® back onto the outline marks made in Step #1. Lightly press into place. Holding onto the Sportwing®, open the deck lid and check to see that the 3/8+holes in the deck lid align with the threaded sleeves of the mounting feet. If satisfied with alignment, press firmly into place. If holes do not align, reposition the Sportwing® until satisfied (**NOTE: if holes and threaded sleeves do not align, open 3/8" holes to the next size**).
5. Using mounting screws, provided, with lock and flat washers, install screws into threaded sleeves of mounting feet and partially tighten all four (4) mounting screws. After all four (4) are started, tighten evenly until tight. **DO NOT OVER TIGHTEN.**
5. Clean up any metal shavings that might have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A

