

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: CHARGER  
FOR: 2006 + Dodge Charger  
EFFECTIVE: 08.17.05

### INSTALLATION PACKAGE INCLUDES:

- A) 4 – ¼ - 20 x 5/8" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Flat Washers
- D) Template
- E) Adhesive Pads (for an unpainted Sportwing®)
- F) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **See Diagram A below.** Starting on the drivers' side, measure down **15 ½"** from the tip of the deck lid where it meets the rear window and make a mark with a grease pencil. Repeat procedure on other side.
2. Place the Sportwing® on the marks made in Step #1, so that as you face the rear of the car, the front tips of the Sportwing® rests on these marks. **See Diagram A below.** Next, center the Sportwing® exactly from left to right. Outline both mounting feet with a grease pencil.
3. Set the Sportwing® aside and position the template provided on the drivers' side outline made in Step #2. Using a 1/8" drill bit or similar, drill down through the spots indicated on the template for your mounting holes (**NOTE: drill only through the top panel of the deck lid for the front mounting hole of the template. When drilling the rear mounting hole, you will need to drill through the top panel and secondary panel of the deck lid. Repeat procedure on passenger side by flipping template over**). Next, using a #1 uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open the 1/8" pilot holes to 3/8".
4. Open the deck lid. Holding Sportwing® onto the outline marks that you made in Step #2, and using mounting screws with lock washers and flat washers, install screws into threaded sleeve on bottom of mounting foot. Finger tighten all four screws then tighten evenly using a ratchet with 3/8" socket. **DO NOT OVER TIGHTEN.**
5. Clean up any metal shavings that might have fallen into the trunk and you are done. Replace trunk liner. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

