

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

SS

PART NUMBER: CIV01-4DR
FOR: 2001 + Honda Civic 4 Door
EFFECTIVE: 11.10.05

INSTALLATION PACKAGE INCLUDES:

- A) 4 – ¼ - 20 x ½" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Hole Locators
- D) 2 – Electrical Connectors
- E) ¼" Wire Harness
- F) Template
- G) Adhesive Pads (for an unpainted Sportwing®)
- H) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Close trunk. **See Diagram A below.** Along the drivers' side, measure down 8 ½" from the tip of the trunk lid, back towards the rear of the car and make a mark with a grease pencil. Repeat on passenger side.
2. Place the Sportwing® on the marks made in Step #1. **See Diagram A below.** As you face the rear of the car, the front tip of the Sportwing® rests on the mark. Center the Sportwing® exactly from left to right. Using a grease pencil, outline both mounting feet. Remove Sportwing® from the trunk.
3. Remove the Sportwing® and position the template provided on the passenger side outline made in Step #2. Using a 5/32" drill bit, drill pilot hole through the spot indicated for the wire harness. When drilling for the wire harness hole, drill through the first panel only. Enlarge harness pilot hole to 3/8". We suggest using a uni-bit for a cleaner cut.
4. Place the hole locators provided inside each of the threaded mounting sleeves of each mounting foot. A piece of masking tape is helpful in holding the hole locators in place. Next, set the Sportwing® back onto the outline marks that you made in Step #2. Using masking tape or electrical tape, tape the hole locators to the deck lid so that when you carefully lift the Sportwing® off the hole locators they will stay in place on the deck lid. Using a 1/8" drill bit or similar, drill a 1/8" pilot hole through the exact center of each of the hole locators through the deck lid. After drilling all four (4) mounting holes, remove the hole locators and open the 1/8" pilot holes to 3/8". We suggest using a uni-bit to open the 3/8" holes for a cleaner cut.
5. Open the deck lid and holding onto the Sportwing®, install mounting screws with lock washers and flat washers provided. Do not tighten until all four screws are started. Then, using a ratchet with 3/8" socket, tighten firmly. **DO NOT OVER TIGHTEN.**
6. Feed the brake light wires of the Sportwing® through the ¼" wire harness provided. Using black electrical tape, fasten this harness neatly along side the factory harness, which runs down the passenger side trunk hinge. Be sure to leave enough slack for opening and closing trunk lid. Run the wires toward the passenger side taillight assembly and using the top plug of taillight, connect the Sportwing® hot wire to the white wire with black stripe and silver slashes. Connect the ground wire to the black wire with silver slashes. Test the connections by stepping on the brake pedal.
7. Clean up any metal shavings that might have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

