

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: COBALT-2DR
FOR: 2005 + Chevrolet Cobalt 2 Door
EFFECTIVE: 06.15.09

INSTALLATION PACKAGE INCLUDES:

- A) 4 – Mounting Screws M6 – 5/8"
- B) 4 – Lock Washers
- C) 4 – Flat Washers
- D) 1 – Template (*drivers' side – flip template over for passenger side*)
- E) Adhesive Pads (*for unpainted Sportwing®*)
- F) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **See Diagram below.** Starting on the drivers' side, measure down 4 ¾" from the tip of the deck lid where it meets the rear window and make a mark with a grease pencil. Repeat procedure on other side.
2. Leaving the paper liner on the bottom of the Sportwing®, place the Sportwing® on the marks made in Step #1 so that as you face the rear of the car, the front tips of the Sportwing® rests on these marks. Next, center the Sportwing® from left to right. Outline both mounting feet with a grease pencil.
3. Set the Sportwing® aside and position the template provided on the drivers' side outline made in Step #2. Using a 1/8" drill bit or similar, drill down through the spots indicated on the template for your mounting holes through the top panel of deck lid only. Repeat on passenger side by flipping template over. After drilling all four holes, open each hole to 7/16" using a uni-bit. We suggest using a uni-bit for a cleaner cut.
4. Close the trunk and remove the paper liner from the bottom of the mounting feet and lightly place the Sportwing® back exactly onto the outline marks made in Step #2. Holding onto the Sportwing®, open the deck lid to make sure you have access to all four threaded sleeves in bottom of mounting feet, if not, relocate Sportwing® until you have access to all four (4) threaded sleeves, then press firmly into place.
5. Install mounting screws with flat washers and lock washers, provided, into threaded sleeves of mounting feet and tighten firmly. **DO NOT OVER TIGHTEN.** Repeat procedure on other side.
6. Clean up any metal shavings that may have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

