

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: CTS
FOR: 2003 + Cadillac CTS
EFFECTIVE: 12.21.05

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 1" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Small Flat Washers
- D) 4 – Black Hole Caps
- E) Template
- F) Adhesive Pads (for an unpainted Sportwing®)
- G) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **See Diagram below for placement of Sportwing® on deck lid.**
2. Leaving paper liner on bottom of mounting feet, place the Sportwing® on the deck lid and center left to right. Measure 3/8" from definite body crease toward the front of the car and place a mark with a grease pencil. Place rear most edge of Sportwing® on the grease pencil marks and re-center Sportwing® left to right. Outline both mounting feet with a grease pencil.
3. Remove the Sportwing® and position the template provided on the drivers' side outline made in Step #2. Using a 5/32" drill bit, drill down through the spots indicated for your mounting holes (**NOTE: you will need to drill through the second panel when drilling your mounting holes but be careful not to drill into the rain channel**). Flip template over and repeat procedure on other side.
4. Open the trunk. Using a 5/8" hole saw, open the mounting holes in the secondary panel to give you access for your socket wrench later. Repeat procedure on other side. Hole caps have been provided upon finishing.
5. Close the trunk and remove the paper liner from the bottom of the mounting feet and place the Sportwing® back onto the outline marks made in Step #2. Press firmly into place.
6. Open the trunk and switch back to a 5/32" drill bit and drill up into the bottom of the mounting feet using a 5/32" holes drilled in Step #3 (NOTE: when drilling, you must use a drill stopper to prevent from drilling through the top of the Sportwing). Using a ratchet with 5/16" socket tighten the mounting screw, lock washers and flat washers. Tighten firmly but **DO NOT OVER TIGHTEN**. Repeat procedure on other side. Place the black hole caps provided over your socket wrench access holes when finished.
7. Clean up any metal shavings that might have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

