

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: FTS-TC
FOR: 2005 + SCION TC
EFFECTIVE: 10.23.06

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 1" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – 5/8" Black Hole Plugs
- D) Template
- E) Adhesive Pads (for an unpainted Sportwing®)
- F) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Along the drivers side, measure ¼" from the trunk lid where it meets the rear glass back toward the rear of the car and place a mark with a grease pencil. Repeat procedure on other side. See Diagram C on back of sheet.
2. Place the Sportwing® on the marks that you made in Step #1, so that the front edge of the Sportwing® rests on the pencil marks, see Diagram C on back of sheet. Center the Sportwing® from left to right and then outline the mounting feet with a grease pencil.
3. Set the Sportwing® aside and place the template provided on the drivers side outline and drill down through the spots indicated using a 5/32" drill bit (**NOTE: when drilling through top panel, you will need to continue drilling through secondary panel of hatch.** After drilling pilot holes through secondary panel, you will need to open polot holes only in the secondary panel to 5/8" using a 5/8" hole saw. This will give you access to the top panel of hatch for your socket wrench later in the installation. Hole caps have been provided for these holes upon finishing). Flip template over for passenger side and drill through the same spots.
4. Peel the paper liner from the bottom of mounting feet and place the Sportwing® back onto the outline marks made in Step #2. Press firmly into place.
5. Open the trunk and using the pilot holes drilled in Step #3, drill up into the bottom of the mounting feet using a 5/32" drill bit (**NOTE: when drilling, we insist using a drill stopper to prevent from drilling up through the top of the Sportwing®.**) Install 1" mounting screws with lock washers using a ratchet with 5/16" socket and tighten firmly. Repeat procedure on other side.
6. Clean up any metal shavings that might have fallen into the trunk and you are done. The installation should take no longer than 30 minutes. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

To remove hatch cover, first remove two Phillips Screws



Diagram B
After removing light gray panels, carefully pry this area down.
(NOTE: prongs are holding liner in place).



Diagram C

