

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: G6-2DR
FOR: 2006 + PONTIAC G6 2 DOOR
EFFECTIVE: 06.05.07

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 3/4" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Black Hole Caps
- D) Template
- E) Adhesive Pads (for an unpainted Sportwing®)
- F) Instruction Sheet

DRILL BITS NEEDED:

- 1. 1/8" or similar – for drilling through deck lid and secondary panel
- 2. Uni-bit to open 1/8" pilot holes to 3/8"
- 3. 5/8" hole saw to open 1/8" holes in secondary panel to give you access to the top panel of deck lid

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

- 1. See Diagram A below. Starting on the driver's side, measure down 10 1/2" from the tip of the trunk lid where it meets the rear window and make a mark with a grease pencil. Repeat procedure on passenger side.
- 2. Leaving paper liner on the bottom of the Sportwing®, place the Sportwing® on the marks made in Step #1 so that as you face the rear of the car, the front edge of the Sportwing® rests on these marks. Next, center the Sportwing® from left to right. Outline both mounting feet with a grease pencil.
- 3. Set the Sportwing® aside and position the template provided on the drivers side outline made in Step #2 (**NOTE: before drilling through the drivers side of deck lid and secondary panel make sure that the factory wire harness in drilling area is pushed aside**). Using a 1/8" or similar drill bit, drill down through the spots indicated on the template for your mounting holes through the top panel and through the secondary panel also. Repeat on passenger side by flipping template over. Next, using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to pen the 1/8" pilot holes on top panel of deck lid to 3/8".
- 4. Open the trunk. Using a 5/8" hole saw, open the 1/8" pilot holes in the secondary panel to 5/8". This will give you access for your socket wrench later in the installation. Repeat procedure on other side. Hole caps have been provided upon finishing.
- 5. Close the trunk and remove the paper liner from the bottom of the mounting feet and place the Sportwing® back onto the outline marks made in Step #2. Press firmly into place.
- 6. Open the trunk and using a ratchet with 5/16" socket, install mounting screws with flat washers and lock washers into the pre-existing fastening holes located on bottom of mounting feet and tighten firmly. **DO NOT OVER TIGHTEN.** Repeat procedure on other side.
- 7. Clean up any metal shavings that may have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number on the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

