

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: MUS05
FOR: 2005 + FORD MUSTANG
EFFECTIVE: 01.11.07

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 3/4" Heavy Thread Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Flat Washers
- D) 1 – Allen Wrench (*****NOTE: use Allen Wrench in drill at slow speed to install screws in fastening holes of Sportwing®**)
- E) Template
- F) Adhesive Pads (for an unpainted Sportwing®)
- G) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Diagram A below. Starting on the drivers side, measure down 10" from the tip of the trunk lid back toward the rear of the car and place a mark with a grease pencil. Repeat procedure on other side.
2. Leaving the paper liner on the bottom of mounting feet, place the Sportwing® on the marks made in Step #1 so that as you face the rear of the car, the front tips of the Sportwing® rests on the mark. *See Diagram A below.* Next, exactly center the Sportwing® from left to right. Outline both mounting feet with a grease pencil.
3. Set the Sportwing® aside and position the template provided on the drivers side outline made in Step #2. Using a 1/8" drill bit or similar, drill down through the spots indicated on the template for your mounting holes through the top panel only. Repeat on passenger side by flipping template over. Next, using a #1 uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open the 1/8" pilot holes to 7/16".
4. Peel the paper liner from the bottom of the mounting feet and lightly place the Sportwing® back onto the outline marks that you made in Step #2. Holding onto the Sportwing®, open deck lid to make sure that the holes in the deck lid align with the holes in the bottom of the Sportwing®. If not, lift the Sportwing® and re-align so all holes are aligned. Using a drill, set at a slower speed with Allen Wrench provided, install mounting screws with lock washer and flat washer into the mounting holes in the bottom of the mounting foot. Tighten all four screws evenly. **DO NOT OVER TIGHTEN.**
5. Clean up any metal shavings that might have fallen in the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

