

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 642-5505
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

FOR: 2010 & Up Ford Fusion
PART NO: RFX-3-FUS (3 piece kit)
EFFECTIVE: 25 JAN 2011

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

Front Ground Effect Installation-

1. **CLEAN AND PREP:**

Using alcohol wipes, provided, clean the area where Front Ground Effect is to be installed.

Where cooler temperatures prevail, make sure that the Front Ground Effects are at room temperature. When installing, the recommended surface of the vehicle should be at least 75°F/24°C for proper installation. If the surface is cold, use a heat gun or hair dryer to warm before proceeding with the installation.

2. **ALIGNMENT:**

See Diagram. Measure down 2" from the top edge of the factory crease, using a grease pencil, as shown, and make a mark. Repeat on other side.

3. Next, measure out 14" from the end of the wheel well, as shown in the **Diagram** and place a mark with a grease pencil. Repeat on other side.

4. **INSTALLATION:**

Using Pro-Bond Adhesive Promoter in the crush-swab self-applicator, squeeze the applicator until you feel the applicator crush, the applicator will become wet at the end and is ready for use. **DO NOT APPLY PRO-BOND ON SURFACE THAT WILL NOT BE COVERED** by the Ground Effect because Pro-Bond may dull the surface. Quickly apply a thin coat of Pro-Bond from the wheel well moving towards the front of the car being careful not apply Pro-Bond further than the Front Ground Effect will cover. Allow Pro-Bond to dry approximately one to two minutes.

5. Peel back approximately 1/3 of the red liner, removing the rest of the liner as you install. (**Note: Do not touch tape adhesive with fingers**).

6. **Using the Diagram as a guide**, begin lightly tacking Ground Effect to the body, starting 1/8" from the wheel well opening (NOTE: This will ensure Ground Effect is centered on front of car) making sure to meet the 14" mark made in Step #4 as applied.

7. Follow the body edge with the molding until meeting the 14" mark on opposite side. Then taper down to the wheel well opening 2" mark made in Step #2.

8. When satisfied with the install, use a soft cloth to firmly press the Front Ground Effect permanently into place.

