

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: SEB07-4DR
FOR: 2007 + Chrysler Sebring 4 Door
EFFECTIVE: 02.21.07

INSTALLATION PACKAGE INCLUDES:

- A) 4 – ¾" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Black Hole Caps
- D) Adhesive Pads (*if ordering unpainted Sportwing®*)
- E) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Remove truck liner.
2. Remove trunk cover, see DIAGRAM A on back of sheet. Starting on drivers' side, measure back 7 ¼" from the tip of the deck lid, where it meets the rear window, and make a mark with a grease pencil. Repeat procedure on other side.
3. Leaving paper liner on bottom of the mounting feet, place the Sportwing® on the marks made in Step #1 so that as you face the rear of the car, the front edge of the Sportwing® rests on these marks. Next, center the Sportwing® from left to right. Outline both mounting feet with a grease pencil.
4. Set the Sportwing® aside and position the template provided on the drivers' side outline made in Step #3. Using a 5/32" drill bit, drill straight down through the spots indicated on the template, through the top panel of the deck lid, for your mounting holes. After drilling through the top panel, you will also need to continue to drill through the secondary panel of the deck lid. However, **BEFORE** drilling through secondary panel of the deck lid, **see DIAGRAM B on the back of sheet** so that you can see where the drill bit should exit the secondary panel (**NOTE: when drilling through the secondary panel of the deck lid, slightly lift the deck lid when drilling to AVOID drilling into the trunk gasket or rain channel of trunk**). After drilling through the secondary panel, you will need to open the deck lid and open the 5/32" pilot holes that you just made in the secondary panel. Using a 5/8" hole saw, open 5/32" pilot holes to 5/8". This will give you access for your drill bit and socket wrench later. Hole caps have been provided to cover these holes upon finishing.
5. Close the trunk and remove the paper liner from the bottom of the mounting feet and place the Sportwing® back onto the outline marks made in Step #2. Press firmly into place.
6. Open the trunk and using a 5/32" drill bit, drill up into the bottom of the mounting feet using the 5/32" pilot holes drilled in Step #4 in top panel of the deck lid (**NOTE: when drilling, you must use a drill stopper to prevent from drilling through the top of the Sportwing®**). Using a ratchet with a 5/16" socket, install mounting screw with lock washers and tighten firmly. **DO NOT OVER TIGHTEN**. Repeat procedure on other side. Then, cover holes in secondary panel with black hole caps, provided. Replace trunk liner.
7. Clean up any metal shavings that may have fallen into the trunk. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.