

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: SEDONA06
FOR: 2006 + Kia Sedona
EFFECTIVE: 08.08.06

INSTALLATION PACKAGE INCLUDES:

- A) 2 – 1" Mounting Screws
- B) 2 – Lock Washers
- C) 2 – Flat Washers
- D) Adhesive Pads (for an unpainted Sportwing®)
- E) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Wear proper eye protection and make sure where Sportwing® will be installed is at room temperature, clean and free of wax.
2. Leaving paper liner on bottom of mounting area, center the Sportwing® left to right on the vehicle and position the Sportwing® for installation. **See Diagram A below.** Using a great pencil, outline outer mounting area of Sportwing® so that later on in the installation you will be able to place the Sportwing® back to desired position.
3. Peel liner from tape and place the Sportwing® back onto the outline marks made in Step #2. Press firmly into place. Open the hatch (**NOTE: prior to drilling, it is important to protect the installation area. Place a drop cloth in this area to prevent shavings from accumulating in drip well channel and bumper area.**)
4. **See Diagram B on back of sheet for drilling locations.** Starting on the drivers side, notice one (1) circular factory cut out hole covered by a black rubber plug. Remove plug and using a 5/32" drill bit (**IMPORTANT NOTE: before drilling holes, we insist that you use a drill stopper to prevent from drilling through the top of the Sportwing®. DO NOT allow more than 3/4" of your drill bit to extend past the drill stopper. Electrical tape, taped tightly around drill bit will work as a drill stopper.**) Using a 5/32" drill bit, drill through the center of this hole, drilling through the hatch and up into the bottom of the mounting area of the Sportwing® using a ratchet with 5/16" socket, install mounting screw, lock washer and flat washer. **See Diagram D on back of sheet (NOTE: the flat washer should lie flat against the secondary panel. DO NOT open secondary panel or fastening screw will be too long and would exit through top of Sportwing®).** Tighten firmly. Repeat procedure on passenger side. Replace factory black plugs.
5. Clean up any metal shavings. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A



DIAGRAM B



Starting on the drivers' side, remove black factory plug. Using 5/32" drill bit with drill stopper (**NOTE: we insist that you use a drill stopper when drilling to prevent from drilling through the top of the Sportwing®.** Electrical tape, wrapped tightly around the drill bit will work as a drill stopper. Only extend drill bit no more than 3/4" past drill stopper. See **Diagram C below**). Drill 5/32" hole through the center of the cut out hole, **as shown in Diagram B above**, through the top panel of hatch and into the bottom of the mounting area of the Sportwing®. Using a 5/16" socket with ratchet, install mounting screw with lock washer and flat washer. See **Diagram D below for placement of flat washer**. Tighten firmly. **DO NOT OVER TIGHTEN.** Repeat procedure on passenger side.

DIAGRAM C



5/32" Drill Bit

DIAGRAM D



Place screw through the factory cut out hole and resting the flat washer with lock washer onto the secondary panel of hatch.