

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: STR-SEB-2DR  
FOR: 2001 + Chrysler Sebring 2 Door  
EFFECTIVE: 09.20.00

### INSTALLATION PACKAGE INCLUDES:

- A) 2 – 5/8" Mounting Screws
- B) 2 – Lock Washers
- C) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Starting on the drivers' side, measure 9 5/8" from the tip of the deck lid where it meets the rear window, **see Diagram A below**. Place a mark on the deck lid with a grease pencil. Repeat procedure on other side.
2. Leaving paper liner on tape, center the Sportwing® left to right on vehicle and position the Sportwing® for installation. Using a grease pencil, outline both mounting feet. Set Sportwing® aside.
3. Leaving the tailgate open and using template provided, place template on outline marks made in Step #2 and using a 5/32" drill bit, drill down through the spots indicated on template, making sure that you do not drill into the rain channel (**NOTE: one of the two holes drilled per side, you will have to drill through a double panel. When coming through the second panel, try to stay on flat area so hole cap will fit flush. When drilling hole through both panels on drivers' side below Sportwing®, loosen the wire harness**). Hole caps have been provided to cover these holes upon finishing. Using a 5/8" hole saw, open up your pilot holes drilled in secondary panel to give you access for your socket wrench later. Flip template over for passenger side and repeat procedure. Remember to push wire harness plug back in.
4. Peel liner from tape and place Sportwing® back onto the outline marks made in Step #1. Press firmly into place.
5. Open the hatch (**NOTE: prior to drilling, it is important to protect the installation area. Place a drop cloth in this area to prevent shavings from accumulating in drip well channel and bumper area**). Using a 5/32" drill bit, drill through the pilot holes up into the mounting feet (**NOTE: when drilling, you must use a drill stopper to prevent from drilling through the top of the Sportwing®**). Install mounting screws with lock washers and tighten. **DO NOT OVER TIGHTEN.**
6. Clean up any metal shavings that may have fallen into the trunk. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.



Finished Installation