

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: STR-SEB-4DR
FOR: 2001 + Chrysler Sebring 4 Door
Dodge Stratus 4 Door
EFFECTIVE: 09.29.00

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 1" Mounting Screws
- B) 4 – Lock Washers
- C) Template
- D) Adhesive Pads (for unpainted Sportwing®)
- E) Instruction Sheet

EXTRA TOOLS NEEDED:

- 1. 3/16" Extra Long Drill Bit (12") – can be purchased at most hardware stores
- 2. 6" Extension for Socket Wrench

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Starting on the drivers' side, measure 18 ¼" from the tip of the deck lid where it meets the rear window. Repeat procedure on other side. **See Diagram below.** Make a mark with a grease pencil (**NOTE: measurement need to be exact so that you will be able to use the factory cut out holes in the second panel of the trunk**).
2. Place the Sportwing® on the marks made in Step #1 so that as you face the rear of the car, the front edge of the Sportwing® rests on these marks. Next, center the Sportwing® from left to right. Outline both mounting feet with a grease pencil (**NOTE: make sure that the Sportwing® does not hit the factory mounted antenna when opening trunk. If it does not close, move the Sportwing® slightly towards the driver side. You can also bend curve the antenna outward**).
3. Remove the Sportwing® and position the template provided on the drivers' side of the outline made in Step #2. Using a 3/16" drill bit, drill down through the spots indicated for your mounting feet. Flip template over and repeat procedure on other side.
4. Close the trunk and remove the paper liner from the bottom of the mounting feet and place the Sportwing® back onto the grease pencil marks made in Step #2. Press firmly into place.
5. Open the trunk and using a 3/16" extra long drill bit, drill up into the bottom of the mounting feet using the pilot holes drilled in Step #3 (**NOTE: when drilling, you must use a drill stopper to prevent from drilling through the top of the Sportwing®**). Install mounting screws with lock washers and tighten firmly. **DO NOT OVER TIGHTEN.** Repeat procedure on other side.
6. Clean up any metal shavings that may have fallen into the trunk. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

