

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: VWB
FOR: 1999 + Volkswagen Beetle
EFFECTIVE: 11.02.99

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 3/4" Mounting Screws
- B) 4 – Lock Washers
- C) 2 – Black Caps
- D) Adhesive Pads (*for unpainted Sportwing®*)
- E) Template
- F) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Place the Sportwing® on designated area. **See Diagram below.** Center the Sportwing® from left to right and outline both mounting feet with a grease pencil.
2. Remove the Sportwing® and position the template, provided, on the outside edge of the trunk lid. Before drilling, make sure the two spots on the template will be covered by the mounting foot. Using a 5/32" drill bit, drill down through the spots indicated for your mounting holes. When drilling, you will need to go through a double panel. Open trunk and open second panel with a 5/8" hole saw. This will give you access for your socket wrench later (**NOTE: on some models, you will need to hole saw on passenger side, where there is a metal brace. Hole saw through the brace and second panel**). Flip template over for passenger side. Repeat procedure on other side.
3. Close the trunk and remove the paper liner from the bottom of the mounting feet. Position the Sportwing® on the outline marks made in Step #1 and press firmly into place (**NOTE: the Sportwing® will not fit completely flush on the car until screws are tightened down**). When drilling holes into the Sportwing®, it is important to drill the inside hole first. This is the hole that you used your 5/8" hole saw on. After drilling hole, install mounting screw and tighten. Next, drill outside hole using the same procedure.
4. Open the trunk. Using a 5/32" drill bit, drill up through the bottom of each of the mounting feet, using the mounting holes drilled in Step #2 (**NOTE: when drilling, a drill stopper must be used to prevent from drilling through the top of the Sportwing**). Install mounting screws with washers and tighten firmly. **DO NOT OVER TIGHTEN.** Replace black trunk panel. Repeat procedure on other side.
5. Clean up any metal shavings that may have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises, Inc.

