

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.Dawn-Ent.com

INSTALLATION INSTRUCTIONS

**BODY SIDE MOLDING REMOVAL
FOR: ALL VEHICLES
EFFECTIVE: 10.20.2016**

TOOLS NEEDED:

- 1 X FISHING WIRE / STRONG STRING
- 2 X TOOLS (SCREWDRIVERS, ETC.)
- 1 X DE-GREASING PRODUCT (OPTIONAL)

Wrap fishing wire / string around two separate tools (screwdrivers work best). Leave about 6" of the fishing wire / string between the two.

At the corner of the moldings, slip the string between the moldings and the vehicle. Work the fishing wire / string back and forth. This will cut the 3M tape. Do this until you can grab some of the molding with your hand. Push downward, toward the ground, this helps to release the tape from the vehicle.

You may see some tape left on the vehicle; use your thumb to rub this off. A de-greasing product should help to soften the tape.

It's not easy, and will take some time, but you will not damage the paint!

