



INSTALLATION GUIDE

DAWN ENTERPRISES INC.

9155 Sweet Valley Drive
Valley View, OH. 44125
(216) 447-1777 Or (800) 548-4867
www.Dawn-Ent.com

Heat Disclaimer: Do not stretch moldings when installing in air temperatures ranging from 60-100° (Fahrenheit). Moldings may be subject to stretching when hot. Make sure wheel temp is over 70°.



Step 1

To ensure rim edge is cleaned thoroughly use the alcohol pads provided.



Step 2

Apply pro-bond to surface where Wheel Trim™ will be applied.



Step 3

Peel back about 3'' of the Wheel Trim's™ red liner. Start applying Wheel Trim™ from the top of the wheel working your way around. Make sure to only pull 3'' of red liner at a time.



Step 4

Press firmly along the Wheel Trim™, making sure it's installed evenly and is adhering to your wheel properly. We recommend using a cloth to protect the surface of Wheel Trim™.