

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.Dawn-Ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: CAMARO16-FM-3PC
FOR: 2016+ Chevrolet Camaro
EFFECTIVE: 9.17.2018

INSTALLATION PACKAGE INCLUDES:

- A) 4 – Paper Hole Locators
- B) 4 – Lock Washers
- C) 4– Flat Washers
- D) 4 – M6 x 1/2" Screws
- E) 1 – Adhesive Promoter Crush Swab

F) Instruction Sheet

EXTRA TOOLS NEEDED:

- 1. 1/8" Drill Bit
- 2. Uni-Bit
- 3. Grease Pencil

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Remove Trunk Liner.
2. Place Sportwing® on decklid, then make an outline around the Sportwing® with a grease pencil.
3. Next, remove the Sportwing® and place upside down on soft surface to prevent scratching and place the provided 4 hole locators on the Sportwing® as shown in **Diagram A**.
4. Place Sportwing® back into outline marks made in Step #2. Tape the 4 paper hole locators to the deck lid using masking tape. Then, remove Sportwing® so that the paper hole locators remain on the deck lid.
5. Next, drill through the 4 hole locators using a 1/8" drill bit. Then, using a unibit, open the holes to 7/16". Be sure to drill through all sheets of metal to allow access from the underside of the trunk lid.
6. Place Sportwing® back in outline and check to make sure that the holes line up. Then, remove red liner from Sportwing® to expose adhesive tape and place back onto deck lid.
7. While holding the Sportwing®, screw in the four (4) screws and washers provided to secure the Sportwing®. Next, take the two end pieces and place them in the intended installation area. Outline these two end pieces with a grease pencil. Set the two pieces aside. Next, within the grease pencil marks you just made, apply half of the Pro Bond™ adhesive promoter crush swab within the grease pencil markings on both sides. Then, after the Pro Bond™ has dried, remove the tape liner and apply the two end pieces to the decklid. After installing the Sportwing®, clean up any metal shavings and wipe off grease pencil marks to complete the installation process. For all questions, please call us toll free at 1.800.548.4867.

DIAGRAM A



Finished Product

