

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125

Phone: (216) 447-1777 or (800) 548-4867

Fax: (216) 642-5505

www.dawn-ent.com

INSTALLATION INSTRUCTIONS

FOR: Sportstyle™ Vents

EFFECTIVE: 5 August 2015

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION**1. LOCATION:**

Place masking tape across vehicle, just above where you'd like the top edge of the vent to sit. Make sure the masking tape is straight before adhering vent. Location will vary from model to model. Please see diagram below for placement suggestions. **NOTE: Must install on a flat surface.**



Use masking tape to guide the placement and installation of each Sportstyle™ Vent.

2. CLEAN AND PREP:

For a proper installation, clean the surface where the Sportstyle™ Vent is to be installed using the included alcohol pads. Wipe off excess residue with a clean cloth.

TEMPERATURE: Where cooler temperatures prevail, make sure the vent is at room temperature. The recommended metal surface temperature of the vehicle should be at least 75°F/24°C for proper installation. If the surface is cold, use a heat gun or hair dryer to warm the surface before proceeding with installation.

3. INSTALLATION:

BEFORE STARTING, peel paper liner from back of vent. **DO NOT TOUCH THE EXPOSED ADHESIVE** with your fingers during the installation (*skin oil will affect adhesion*).

Lightly tack the vent onto the desired position. Make sure you are satisfied with the alignment before pressing the part down and permanently installing the vent. If you would like to adjust the alignment, gently lift the vent off the vehicle and reposition it. Cancelled

When you are satisfied with the vent's alignment and location, use a soft cloth and apply pressure to the entire vent to insure proper adhesion. Remove masking tape, and you will have a Sportstyle™ Vent that will last for many years. Thank you for choosing Dawn Enterprises! If you have any questions, please don't hesitate call the number at the top of the sheet.