

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.Dawn-Ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: MAL16-FM
FOR: 2016+ CHEVY MALIBU
EFFECTIVE: 8.2.2017

INSTALLATION PACKAGE INCLUDES:

- A) 2 – M6 3/8" Bolts
- B) 2 – Hole Locators
- C) 2 – Lock Washers
- D) 2 – Flat Washers
- E) 2 – Pro Bond™ Crush Swabs

EXTRA TOOLS NEEDED: 1/8" drill bit or similar, Uni-Bit for 3/8" holes in top of deck lid, Phillips screwdriver to tighten machine screws.

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Remove trunk liner by removing 9 clips and the trunk latch cover.
2. Place the Sportwing® onto the decklid and measure down 14 5/8" from the tip on the trunk to the tip of the Sportwing® on both the driver and passenger side. (As shown in diagram A below).

(DIAGRAM A)



(DIAGRAM B)



3. Next, take a grease pencil and outline the edges of the Sportwing® on both the driver and passenger sides. Place the Sportwing® aside on a soft cloth to prevent scratching. Proceed to place a cover or blanket inside of the trunk to protect it from metal shavings from drilling. Place the provided hole locators over the screw holes on the Sportwing® (As Shown in Diagram B). Using the outlined marks you made, place the Sportwing® back on the decklid and tape the ends of the hole locators onto the car and carefully lift them off the Sportwing®.
4. Next, drill into the exact center of the hole locator using your 1/8" drill bit. Once the holes are drilled you can remove the hole locators. Now, using a Uni-Bit, open the holes to 3/8". Once the holes are opened, use touch-up paint over the bare metal around the holes. Next, using the 2 supplied Pro Bond™ Crush Swabs, crush the Swabs to activate the adhesive promoter. Apply the promoter to the interior outline of the Sportwing® to make sure the adhesive promoter makes contact with the adhesive tape, and wait about 10 seconds for it to dry. Once dry, you can begin to remove the tape protectors on your Sportwing® and place the Sportwing® in line with the outlined marks you made on the decklid. Check to ensure the screw holes are visible on the underside of the decklid where your drilled holes are. You can now insert both screws into the Sportwing® and tighten (be sure not to over tighten the bolts to avoid stripping them). Once tight you can assemble trunk liner back on.
6. Clean up any metal shavings, and you are done. If you have any questions, or would like more information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.