

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.Dawn-Ent.com

## UNIVERSAL INSTALLATION INSTRUCTIONS

FOR: 2014+ Toyota Corolla  
PART #: RLUR-COR14  
EFFECTIVE: September 19, 2014

### INSTALLATION PACKAGE INCLUDES:

- A) Alcohol Wipes
- B) Adhesive Promoter
- C) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. **LOCATION:**  
**See Diagram A below.**
2. **CLEAN & PREP:**  
For proper installation of roofline spoiler, clean the surface where the roofline spoiler is to be installed using alcohol wipes enclosed. Wipe off excess residue with a clean cloth. Leaving the red tape liner on the bottom of the roofline spoiler, place the spoiler in the position **as shown in Diagram below**. Center left to right so that spoiler is even on both sides. Roofline must be placed with fitted area over third brake light. Next, using a second person, hold the spoiler in desired position and using a grease pencil, outline the rear most edge of the spoiler. This will allow you to place the spoiler back onto the exact area when adhering spoiler into place. Set the roofline spoiler aside. Apply Pro-Bond adhesive promoter in the crush swab self-applicator only to the areas inside of grease pencil outline. Squeeze the applicator until you feel the applicator crush. The applicator will become wet on the end and is ready for use. Quickly apply a coat of Pro-Bond to the outlined area that will be covered by the roofline spoiler. The coat of Pro-Bond will dry quickly. Where cooler temperatures prevail, make sure that the roofline spoiler is at room temperature. The recommended glass surface and roofline spoiler should be at least 75°F/24°C for proper installation. If the surface is cold, use a heat gun or hair dryer to warm before proceeding with the installation.
3. **INSTALLATION:**  
Peel the red liner from the mounting tape and having a second person standing on the opposite side of the vehicle, lightly tack the spoiler back onto the outline marks you made in Step #2. Do not touch the exposed adhesive with your fingers. When satisfied with the placement, press firmly into place using a soft cloth and apply pressure along the entire length of the spoiler to ensure proper adhesion.

### DIAGRAM



DISCLAIMER: Dawn Enterprises, Inc. is not responsible for any damage done by improper installation.