

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: CH-RT  
FOR: 2006-2010 Dodge Charger  
EFFECTIVE: 23 March 2012

### INSTALLATION PACKAGE INCLUDES:

- A) 4 – M6X5/8" Screws
- B) 4 – Flat Washers
- C) 1 – Driver's Side Template – Flip template over for passenger side
- D) Adhesive Pads
- E) Instruction Sheet

### EXTRA TOOLS NEEDED:

- 1. 1/8" Drill Bit
- 2. Uni-Bit

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Place the Sportwing® on the deck lid so that the rear most area of the mounting feet sit 1/8" forward of the definite rear crease of deck lid. Next, center Sportwing® left to right on deck lid. **See Diagram A below.** Outline both mounting feet with a grease pencil.
2. Set the Sportwing® aside and position the driver's side template, provided, on the driver's side outline made in Step #1. Using a 1/8" or similar drill bit, drill down through the exact center of the spots indicated on the template for your mounting holes through the top panel of the deck lid. Next, using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open the 1/8" pilot holes that you made in the top panel of the deck lid to 3/8".
3. Apply Zinc Chromate or touch-up paint on the edges of the four (4) 3/8" holes that you drilled in the deck lid.
4. Place the Sportwing® back onto the outline marks made in Step #1. Lightly press into place. Holding onto the Sportwing®, open the deck lid and check to see that the 3/8" holes in the deck lid align with mounting holes on the bottom of the mounting feet. If satisfied with alignment, press firmly into place. If holes do not align, reposition the Sportwing® until satisfied.
5. Install the four (4) provided M6 x 5/8" screws into the mounting holes of the mounting feet, with the lock and flat washers. Partially tighten all four (4) mounting screws. After all four (4) are started, tighten evenly until tight. **DO NOT OVER TIGHTEN.**
6. Clean up any metal shavings that might have fallen into the trunk and you are done. If you have any questions, or if you would like information about other quality Sportwing® products, please call the TOLL-FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A

