

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: ESCAPE08
FOR: 2008 + Ford Escape
EFFECTIVE: 06.18.08

INSTALLATION PACKAGE INCLUDES:


- A) 2 – M-6 x ¾" Mounting Screws
- B) 2 – Lock Washers
- C) 2 – Flat Washers
- D) 2 – Templates – 1 drivers side and 1 passenger side
- E) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Open hatch. **See Diagram A below.** Notice the oval rubber plug on each side plugged into the secondary panel. Next, you will need to lift off the rubber boot from the plastic oval plug. Using the flat screwdriver, notice on the center top edge of the plug there is a small slot, you will need to press this in to release the plastic oval plug from the secondary panel of the hatch. This will give you access to the top panel of the hatch later on in the installation when fastening Sportwing® to the hatch.
2. **See Diagram B on the back of sheet** for placement of template on the hatch. Starting on the drivers' side, using the drivers' side template, provided, place the template exactly **as shown on Diagram B**. Tape the template in place using masking tape. Next, drill a 1/8" or similar pilot hole through the exact center of the fastening hole spot on the template through the top panel of the deck lid. Next, using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) you will need to open the 1/8" pilot hole that you just made to 7/16". Repeat procedure on passenger side using the passenger side template, provided.
3. Apply Zinc Chromate Primer or touch-up paint on the edges of the two (2) 7/16" holes that you drilled in the hatch.
4. Holding onto the Sportwing®, place the Sportwing® onto the hatch, aligning the threaded mounting sleeves in mounting feet to the 7/16" holes that you made in hatch. Using the mounting screws with lock washers, provided, install screws into the threaded sleeves of the mounting feet. Tighten evenly until tight. **DO NOT OVER TIGHTEN.**
5. Replace rubber boot onto the black oval factory plugs. Then, press the black oval factory plugs back into the secondary panel of hatch that you removed in Step #1.
6. Clean up any metal shavings and you are done. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A

Remove rubber boot. Using small screw driver, press in center tab and remove plug.



See Diagram B on back of sheet

DIAGRAM B

