

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS S.S.

PART NUMBER: FUS10  
FOR: 2010 + Ford Fusion  
EFFECTIVE: 10-18-2011

### INSTALLATION PACKAGE INCLUDES:

- A) 4 – M6 5/8" Mounting Screws
- B) 4 – Lock Washers
- C) 4 – Flat Washers
- D) 1 – Drivers Side Template – Flip template over for passenger side
- E) Adhesive Pads (*for an unpainted Sportwing®*)
- F) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Open the trunk and place a protective cover inside the trunk to capture any metal shavings.
2. Starting on the drivers' side, measure down **12 ¾"** from the front corner of the trunk lid where it meets the rear window glass and make a mark. See Diagram A on back of sheet. Repeat on passenger side.
3. Leaving the paper liner on the bottom of the mounting feet, place the Sportwing® on the marks made in Step #2, see Diagram A on back of sheet, so that as you face the rear of the car, the front tips of the Sportwing® rests on the marks. Center the Sportwing® exactly from left to right. Using a grease pencil, outline both mounting feet.
4. Next, See Diagram B on the back of sheet. Starting on the drivers' side, measure down **14"** from the front corner of the trunk lid where it meets the rear window glass and make a mark. Line up the template, provided, with the edge of the trunk at the **14"** mark.
5. Drill 1/8" or similar holes through the two (2) fastening hole locations on the drivers' side template. Repeat this procedure on the passenger side by flipping template over (**NOTE: when drilling these holes, we insist using a drill stopper to prevent from drilling into the rain channel. Only extend drill bit ½" past drill stopper when drilling these holes**).
6. Using a uni-bit (**NOTE: we suggest using a uni-bit for a cleaner cut**) open the four (4) 1/8" pilot holes drilled in Step #5 to 3/8". After opening holes to 3/8" apply touch up paint or zinc chromate primer on the edges of the 3/8" holes.
7. Remove the paper liner from the bottom of the mounting feet and lightly place the Sportwing® back onto the outline marks that you made in Step #3. Holding onto the Sportwing®, open the deck lid and make sure 3/8" holes in deck lid align with threaded sleeves on bottom of mounting feet. If holes do not align, relocate Sportwing® if necessary or you may have to open 3/8" holes to 7/16". Repeat procedure until alignment is correct. When satisfied with alignment, press firmly into place. Install mounting screws with lock washers and flat washers, tighten screws half way until all four are started then tighten. **DO NOT OVER TIGHTEN.**
8. Clean up any metal shavings that may have fallen into the trunk. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A



DIAGRAM B

