

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS SS

PART NUMBER: MAL08  
FOR: 2008 + Chevrolet Malibu  
EFFECTIVE: 04.25.08

### INSTALLATION PACKAGE INCLUDES:

- A) 6 threaded studs
- B) 6 <sup>1</sup>/<sub>4</sub>" Flange Nuts
- C) 1 – Template (*drivers' side – flip template over for passenger side*)
- D) Adhesive Pads (*for unpainted Sportwing<sup>®</sup>*)
- E) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Remove trunk cover on some models before beginning installation. **See Diagram A on back of page.** Along the drivers' side, measure down **11 ½"** from the tip of the trunk lid, back towards the rear of the car, and make a mark with a grease pencil. Repeat procedure on other side.
2. Leaving paper liner on bottom of mounting feet, place the Sportwing<sup>®</sup> on the marks made in Step #1 so that as you face the rear of the car, the front edge of mounting feet of the Sportwing<sup>®</sup> rests on the marks. **See Diagram B on back of sheet.** Center the Sportwing<sup>®</sup> exactly from left to right. Using a yellow grease pencil, outline both outside mounting feet. Set Sportwing<sup>®</sup> aside.
3. Close the trunk. Starting on the drivers side, using the same **11 ½"** measurement that you made in Step #1, **see Diagram A on back of sheet**, line up the drivers' side template, provided, with the edge of the trunk at the **11 ½"** mark. Flip template over and repeat procedure on passenger side.
4. Drill 5/32" holes through the three (3) fastening hole locations on the drivers' side template through the top panel of the deck lid only. Repeat this procedure on the passenger side by flipping template over (**NOTE: when drilling these holes, we insist using a drill stopper to prevent from drilling into the rain channel. Only extend drill bit ½" past drill stopper when drilling these holes**). After these holes have been drilled remove drill stopper and open the 6 5/32" holes to 7/16" using a uni-bit.
5. Close the deck lid. Using the 6 threaded studs screw them into the Sportwing<sup>®</sup>. Once you've screwed the 6 threaded studs into the Sportwing<sup>®</sup>. Then place Sportwing<sup>®</sup> over the holes that were drilled in step 4. While holding the sportwing in place screw the 6 <sup>1</sup>/<sub>4</sub>" Flange Nuts to secure the Sportwing<sup>®</sup>.
6. Clean up any metal shavings that may have fallen into the trunk and you are done. If you have any questions, problems or if you would like information about other quality Sportwing<sup>®</sup> products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

DIAGRAM A



DIAGRAM B

