

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: SCION-XD
FOR: 2008 + Scion XD
EFFECTIVE: 10.14.08

INSTALLATION PACKAGE INCLUDES:

- A) 4 – Round Tape Gaskets
- B) 4 – M-6 x $\frac{3}{4}$ " Mounting Screws
- C) Lock Washers
- D) Flat Washers
- E) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Open the hatch. Remove plastic panel, removes easily.
2. **See Diagram below.** Notice the four (4) factory fasteners that are holding the factory trim along the rear window (**NOTE: you will need to remove the factory trim piece**). Remove the four (4) factory screws and discard. Set factory trim piece to the side, you will no longer need it.
3. Hold the Sportwing® to the hatch and align the four (4) threaded sleeves of the Sportwing® to the four (4) factory holes in the hatch (**NOTE: notice that the two (2) outermost holes do not quite align to the threaded sleeves, so you will need to open these two (2) holes only to the next size using a uni-bit – we suggest using a uni-bit for a cleaner cut**). Check alignment of the holes, all four (4) holes should now align.
4. Peel the paper liner from the four (4) round tape gaskets and place the four (4) black round tape gaskets centered over the four (4) factory holes in hatch.
5. Using the screws, with lock washers and flat washers, provided, install screws into the threaded sleeves of the mounting area. Only tighten screws partially until all four (4) screws are started, then tighten evenly until tight. **DO NOT OVER TIGHTEN.**
6. Clean up any metal shavings. If you have any questions, problems or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

