

## DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125  
Phone: (216) 447-1777 or (800) 548-4867  
Fax: (216) 447-3416  
www.dawn-ent.com

## INSTALLATION INSTRUCTIONS

PART NUMBER: SPORTAGE11  
FOR: 2011 & Up Kia Sportage  
EFFECTIVE: 24 April 2012

### INSTALLATION PACKAGE INCLUDES:

- A) Alcohol Wipes
- B) Pro-Bond Adhesive Promoter (crush swab)
- C) 2 –Mounting Screws
- D) 2 – Flat Washers
- E) Instruction Sheet

### PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. For proper installation of Sportwing®, clean the surface where the Sportwing® is to be installed using the alcohol pads enclosed. Wipe off any excess residue with a clean cloth. Sportwing® and vehicle should be at room temperature of at least 70°F.
2. Leaving the paper liner on the bottom of the mounting feet, place the Sportwing® onto the hatch of vehicle. Center the Sportwing® from left to right making sure the Sportwing® is laying flush to the hatch. When the Sportwing® is in desired position, outline mounting feet using a grease pencil. This will allow you to place the Sportwing® back to the desired position later in the installation when removing the paper liner.
3. Next, apply Pro-Bond Adhesive Promoter, provided, only to area where mounting feet of Sportwing® will adhere (**NOTE: use Pro-Bond inside of the grease pencil outline that you made in Step #2 only**). Allow Pro-Bond to dry for a few minutes.
4. Peel the paper liner from the tape on the bottom of the mounting feet. Place the Sportwing® back onto the outline marks that you made in Step #2. When satisfied with the alignment, press firmly into place.
5. Notice the cut-out fastening area on the top of Sportwing® (one on each side). Using a 1/8" drill bit, drill one (1) 1/8" hole through the top panel only of the hatch on each side of the vehicle. Before installing screws, apply silicone sealant onto the threads of each mounting screw. Install mounting screws and flat washers. Tighten, but **DO NOT OVER TIGHTEN**. Repeat procedure on other side.
6. Next, remove the tape liner from the two (2) Sportwing® covers (**NOTE: we suggest covers should be at least 75°F when adhering covers onto top of Sportwing®**). Press covers firmly into place to cover mounting screws of Sportwing®.
5. If you have any questions, or if you would like information about other quality Sportwing® products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises Inc.

