

DAWN ENTERPRISES INC.

9155 Sweet Valley Dr., Valley View, OH 44125
Phone: (216) 447-1777 or (800) 548-4867
Fax: (216) 447-3416
www.dawn-ent.com

INSTALLATION INSTRUCTIONS

PART NUMBER: COR09
FOR: 2009 + Toyota Corolla
EFFECTIVE: 03.20.08

INSTALLATION PACKAGE INCLUDES:

- A) 4 – 1" Mounting Screws
- B) 4 – Lock Washers
- C) 2 – Electrical Connectors
- D) 2 – Black Hole Caps
- E) ¼" Wire Harness
- F) 1 – template (*drivers side – flip template over for passenger side – you do not need to drill for harness hole on passenger side – only the two fastener holes*)
- G) Adhesive Pads (*for unpainted Sportwing®*)
- H) Instruction Sheet

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Along the drivers' side, measure **9"** from the tip of the trunk lid back toward the rear of the car and place a mark with a grease pencil. Repeat procedure on other side. **See Diagram A on back of sheet.**
2. Leaving the paper liner on the bottom of the mounting feet, place the Sportwing® on the marks made in Step #1 so that as you face the rear of the car, the front tips of the Sportwing® rests on the mark. Center the Sportwing® from left to right along these marks. Using a yellow grease pencil, outline both mounting feet. Set the Sportwing® aside.
3. Set the Sportwing® aside and place the template, provided, on the drivers' side outline made in Step #2. Using a 5/32" drill bit, drill down through the spots indicated on the template, see template for drilling instructions (**NOTE: after drilling pilot hole for wire harness, you will need to open harness hole to 3/8" using a uni-bit. We suggest using a uni-bit for a cleaner cut.**) Drill harness hole through top panel only. When drilling the two fastener holes per side, you will need to drill the outermost hole on template through the top panel and continue drilling straight down through the secondary panel of the deck lid. **See Diagram B on back of sheet** where the drill bit should exit flat area of secondary panel. When drilling innermost fastening hole on template, you only need to drill through the top panel only. There is a factory cut out in the secondary panel to give you access to the top panel later on in the installation. Flip template over for passenger side and drill only the two fastener holes on the template. No harness hole is needed on the passenger side.
4. Open the trunk. Using a 5/8" hole saw, open up the pilot holes drilled in the secondary panel to 5/8". This will give you access for your socket wrench later. Repeat procedure on other side.
5. Close the trunk. Remove the paper liner from the bottom of the mounting feet and feed the brake light wires through the harness hole made in Step #3 (**NOTE: be careful not to crimp the brake light wires as you position the Sportwing® for installation**). Place the Sportwing® back onto the grease pencil outline marks made in Step #2 and press firmly into place.
6. Open the trunk. Switch back to the 5/32" drill bit and drill up into the bottom of the mounting feet using the mounting holes drilled in Step #3 (**NOTE: when drilling, we insist you use a drill stopper to prevent from drilling up through the top of the Sportwing®**). Using a ratchet with 5/16" socket, install mounting screws with lock washers and tighten firmly. **DO NOT OVER TIGHTEN.** Use the black hole caps, provided, to cover your holes in the secondary panel. Repeat procedure on other side.
7. Run the Sportwing® wires toward the drivers' side trunk hinge and run the Sportwing® wires into the ¼" wires harness, provided. Then, using black electrical tape, fasten the ¼" wire harness, provided, neatly along the drivers' side trunk hinge (**NOTE: be sure to leave enough slack in the wire to allow opening and closing of the trunk**). Next, run the wires inside the drivers' side trunk panel toward the drivers' side taillight assembly. Using the electrical connectors, provided, connect the hot wire of the Sportwing® to the green wire with white stripe. Next, connect the black ground wire of the Sportwing® to the black wire with grey stripe.
8. Clean up all metal shavings and you are done. If you have any questions, problems or if you would like information about other quality Sportwing products, please call the TOLL FREE number at the top of this sheet. Thank you for choosing Dawn Enterprises, Inc.

DIAGRAM A




DIAGRAM B



When drilling outer-most fastening hole on template, you will need to drill through the top panel of the deck lid and continue drilling straight down through the secondary panel.

See Diagram as to where drill bit should exit (**NOTE:** exit hole does not have to be exact as shown in Diagram but black hole cap, provided, should lie flush to the flat area of panel).